

Setting up Chromecast on the MBX-Series products (Recommended for ALL installations)

Setting up Chromecast is quick and easy on the Russound MBX-Series of products. The Google Home app will walk you through all of the steps and can even be used to configure the Wi-Fi settings on a new Russound device. If you don't have the Google Home app yet, please download it from the App Store/Play Store before proceeding.

For Wired Ethernet Installations

1. Make all wiring connections including ethernet and power up the MBX product
2. From a device on the same network as the MBX product, open the Google Home app and select "Discover". Follow the prompts to set up the device.
3. Name the MBX product. Refer to the MBX product's installation manual for recommended names. Note that Google Home appends the word "speaker" automatically. You can remove the "speaker" from the name afterwards by editing the device settings if you don't want it in the device name.
4. Finish configuring the MBX product using WebConfig

For Wi-Fi Installations

1. Make all wiring connections and power up the MBX product
2. From a device on the network that you want to add the MBX product to, open the Google Home app and select "Discover". Follow the prompts to set up the device including appropriate Wi-Fi network settings.
3. Name the MBX product. Refer to the MBX product's installation manual for recommended names. Note that Google Home appends the word "speaker" automatically. You can remove the "speaker" from the name afterwards by editing the device settings if you don't want it in the device name.
4. Finish configuring the MBX product using WebConfig

IMPORTANT NOTE

Ideally, the MBX devices should be set up using the homeowner's iOS or Android device using the homeowner's Google Home app. If this is not possible, the installer can set up the devices on the installer's Google Home app and once configured and named, the homeowner (and anyone else with a Google device on the Homeowner's home network) can cast to and communicate with the MBX products. Only the original Google Home account user can reconfigure/re-name Chromecast devices like the MBX products. This may be advantageous to an installer to make sure that a customer doesn't inadvertently tamper with any device settings and it is up to the installer to decide the best way to install and configure the devices for use with Chromecast for his/her customers.

a sound relationship
Russound